Owner's Manual And Assembly Instructions



The Bellevue

Model: 1-AP012-06

INS-BELLEVUE-06 Rev. 04/10/06



Adventure Playsets

Amarillo Texas 79119

Thank you for purchasing an Adventure Playsets Playcenter. We hope it will bring you and your children many years of safe and

enjoyable backyard fun.

Table of Contents

Letter to Customer	2
Positioning Your Playcenter	3
Tools Required for Assembly	
Holmful Installation Hints	4
Suggested Playground Surfacing	
Operating Instructions	
Maintenance Instructions	7
Disposal Instructions	7
CPSC Information Sheet	
Assembly Instructions	
Frequently Asked Questions	
Customer Notes	
Limited Warranty	35
Warranty Claim Procedure	36
Customer Registration Card	
UK Registration Card	
_	

Your owner's manual should be read carefully before starting assembly.



STOP...PLEASE READ!!

IF YOU HAVE ANY QUESTIONS OR ARE MISSING A PART, PLEASE DO NOT CONTACT THE RETAILER THAT YOU PURCHASED THIS PRODUCT FROM.

PLEASE CALL US DIRECTLY
AT THE FACTORY, 1-800-856-4445,
OUR TRAINED STAFF WILL ANSWER YOUR
QUESTIONS AND OR EXPEDITE PARTS
THAT YOU MAY NEED.

Dear Customer:

Thank you for purchasing an Adventure Playsets Playcenter. We hope it will bring you and your children many years of safe and enjoyable backyard fun. Adventure Playsets equipment is recommended for use by **children 3 to 10 years of age**. Adventure Playsets structures are **not intended for public use**. **Adventure Playsets does not warranty any of its residential structures subjected to commercial use**.



WARNING: This Symbol points out important safety instructions which, if not followed, could endanger the personal safety of yourself and your children and/or damage your property. You MUST read and follow all instructions in this manual before attempting to use this playcenter.



WARNING: Children must NOT use this playcenter until unit has been completely assembled and inspected by an adult to insure set has been properly installed and anchored.

Please follow all recommendations below. Failure to do so may result in the warranty being void and/or safety violations that could result in serious injury. The following information has been provided to help you in your installation, continued satisfaction, and safe operation of your Adventure Playsets purchase.

Always keep the safety of your children in mind as your play structure is being built and as your children play on the set. Before your children play on the set please review the Operation Instructions with them to help ensure their safety.

PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. KEEP THEM IN A SAFE PLACE WHERE YOU CAN REFER TO THEM AS NEEDED.

Please do NOT return the playcenter to the retailer from which it was purchased, without first contacting Customer Service.

General Information:

Please take time and fill out the information below. This information will be needed for warranty issues.


Date of Purchase:	Date stamped on box:	
Manufacturer: Adventure Playsets 14201 Interstate 27	<u>Vendor</u> :	
Amarillo, TX 79119		
Ph. #: 1-800-856-4445		
Fax: 806-622-1515		
E-mail: custservice@adv	ventureplaysets.com	
Website: http://www	.adventureplaysets.com	
Unit Type:		
Unit Name: The Bellevue	Revision Date: <u>09-08-05</u>	
Unit Model Number: <u>1-AP012-06</u>		
Maximum Fall Height:	6'- 11"	

The instructions and owner's manual for your new Playcenter should be read in its entirety before assembly, to minimize problems and safety issues. We recommend reading the owner's manual thoroughly after you have identified all of the parts for your Playcenter as discussed in the Helpful Installations Hints section below.

Positioning Your Play center

- 1. The Playcenter is designed to be installed on a level surface by an Adult with an Adult helper. Try to place in a flat area of your yard to minimize ground preparation.
- 2. Place the equipment not less than 6 ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- 3. It is a good idea to place your Playcenter in an area that is convenient for adults to watch children at play.
- 4. The area that you choose should be policed for glass, rocks or anything jagged or sharp that could endanger your children's safety. The surface underneath your play system can cause or prevent injuries. We have additional suggestions in the Suggested Playground Surfacing Section.
- 5. Do not build your playset on top of surfacing material.

Tools Required for Installation:



Helpful Installation Hints

- 1. Depending on your experience, assembly of this Play set should take approximately 6 to 12 hours after inventory of parts. Therefore, we recommend you set aside a full day for assembly.
- 2. Identify all of the parts for your Playcenter. Empty each box and lay out boards so you can see each part. Your instruction book will have detailed drawings that will make it easy for you to recognize individual parts. Keep all hardware and metal parts separate from wooden pieces.
- 3. After everything is laid out, check carefully to ensure all parts are present. Make sure there are no broken boards.
- 4. Find an area to sort your hardware. It is best to open the hardware on a solid surface so that you do not lose any pieces in the grass. This will save time and familiarize you with all the different pieces in the hardware bag.
- 5. Important note: Wood has some natural defects such as knots, surface cracks, etc... We reject parts that are structurally defective. We use a high quality lumber in our structures; however, you should inspect each part for splinters or rough spots and sand them smooth to prevent injury.
- 6. After steps 1 thru 4 have been completed, read all the way through the instructions completely. Reading instructions after you have studied the parts will help you understand more clearly the installation process, and help to eliminate unnecessary mistakes.
- 7. Pay close attention to the diameter and length of each bolt and screw. There will be different sizes in the same bag, so they must be sorted correctly.
- 8. Swing hangers should be buried past the threads, so that the loop is against the swing beam. Adventure Playsets is not responsible for incorrect installations of swing hangers. Failure to properly install swing hangers may cause severe injury.
- 9. Never tighten hardware completely at first. It helps to have some adjustment for bolt alignment while you are attaching parts together. After everything is square, tighten each joint.
- 10. After the main unit is assembled it is critical that the floor is level and square. If the main frame is not level, the walls and floor will be out of square.
- 11. After you complete installation, make sure every bolt, screw, and nut is tight, and every board is secure. Wood will expand and contract with the seasons. Check all bolt connections and swing hangers every two weeks.
- 12. Place the set on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.

READ! VERY IMPORTANT!

If you are missing parts or have questions regarding the installation of our quality product PLEASE call us directly at the factory (1-800-856-4445). Our trained staff will be happy to assist you.

Customer service hours: Monday thru Friday 9am to 5pm Saturday 9am to 2pm Central Standard Time.

E-mail: custservice@adventureplaysets.com

ATTENTION: UK CUSTOMERS

We thank you for purchasing our excellent quality play equipment.

We are sure that you will be satisfied with your selection. However, should you experience any problems or require any advice, do not return the item to the store, please contact our European Customer Service Number below. To ensure a prompt and efficient handling of your query please have your assembly instructions ready when you call.

Tel: 08700 170580 or email us at info@plumproducts.com

Suggested Playground Surfacing

- □ Playground equipment should never be placed on hard surfaces such as concrete or asphalt.
- □ Shredded bark mulch, wood chips, fine sand and fine gravel, are added as shock absorbing materials after assembly. If used properly these materials can absorb some of the impact of a child's fall.
- □ All surface material should extend a minimum of 6 feet in all directions around the play area.

The following chart explains the fall height in feet from which a life threatening head injury would not be expected

Critical Heights in feet (m) of Tested Materials

Material	Uncompressed Depth		ressed Depth Compressed Depth	
	6" (152mm)	9" (228mm)	12" (304mm)	to 9" (228mm)
Wood Chips	7' (2.13m)	10' (3.05m)	11' (3.35m)	10' (3.05m)
Double-Shredded bark mulch	6' (1.83m)	10' (3.05m)	11' (3.35m)	7' (2.13m)
Engineered Wood Fibers	6' (1.83m)	7' (2.13m)	>12' (3.66m)	6' (1.83m)
Fine Sand	5' (1.52m)	5' (1.52m)	9' (2.74m)	5' (1.52m)
Coarse Sand	5' (1.52m)	5' (1.52m)	6' (1.83m)	4' (1.22m)
Fine Gravel	5' (1.52m)	7' (2.13m)	10' (3.05m)	6' (1.83m)
Medium Gravel	5' (1.52m)	5' (1.52m)	6' (1.83m)	5' (1.52m)
Shredded Tires*	10-12' (3.0-3.6m)	N/A	N/A	N/A

*This data is from tests conducted by independent testing laboratories on a 6-inch depth of uncompressed shredded tire samples produced by four manufacturers. The tests reported critical heights, which varied from 10 feet to greater than 12 feet. It is recommended that persons seeking to install shredded tires as a protective surface request test data from the supplier showing the critical height of the material when it was tested in accordance with ASTM F1292.

Operating Instructions:



NOTE: Your children's safety is our #1 concern. Observing the following statements and warnings reduces the likelihood of serious or fatal injury. Please review these safety rules regularly with your children.

- 1. This Playcenter is designed for the use of 3 occupants who have a combined weight not exceeding 280 pounds.
- 2. On-site adult supervision is **required**.
- 3. Instruct children **not** to walk close to, in front of, behind, or between moving swings or other moving playground equipment.
- 4. Instruct children to sit in and **never** stand on swings
- 5. Instruct children **not** to twist the chains and ropes and not to loop them over the top support bar, since this may reduce the strength of the chain or rope.
- 6. Instruct children **not** to jump from swings or other playground equipment in motion.
- 7. Instruct children to **not push** empty seats. The seat may hit them and cause serious injury.
- 8. Instruct and teach children to sit in the center of the swings with their full weight on the seats.
- 9. Instruct children **not** to use the equipment in a manner other than intended.
- 10. Instruct children to **always** go down slides feet first. Never slide headfirst.
- 11. Instruct children to **look** before they slide to make sure no one is at the bottom.
- 12. Instruct children to **never** run up a slide, as this increases their chances of falling.
- 13. The parents should have the children **dress appropriately** with well-fitting shoes. Loose clothing such as scarves and ponchos should not be worn. Always take off, tie up or tuck in cords and drawstrings on children's clothing. These things can get caught on playground equipment and strangle a child.
- 14. Instruct children **not** to climb when the equipment is wet.
- 15. Instruct children to **never** jump from a fort deck. They should always use the ladder, ramp or slide.
- 16. Instruct children to **never** crawl or walk across the top of monkey bars.
- 17. Instruct children to **never** crawl on top of a fort roof.
- 18. Verify that any suspended climbing ropes, chain, or cable are secured at both ends and that they cannot be looped back on it.
- 19. Instruct children **not** to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
- 20. Instruct children to **never** use Monkey Bar when swings or glider are in use.
- 21. Instruct children to **never** wrap their legs around swing chain.
- 22. Instruct children to **never** slide down the swing chain.

Maintenance Instructions:

- 1. Check all nuts and bolts twice monthly during the usage season and tighten as required. (But not so tight that you crack the wood) We recommend you check the swing beam and hardware every two weeks due to wood expansion and contraction. It is particularly important that this procedure be followed at the beginning of each season.
- 2. Remove plastic swing seats and take indoors or do not use when the temperature drops below 32 °F.
- 3. Oil all metallic moving parts monthly during the usage period.
- 4. Check all coverings for bolts and sharp edges twice monthly during usage season to be certain they are in place. Replace when necessary. It is especially important to do this at the beginning of each new season.
- 5. Check swing seats, ropes, cables and chains monthly during usage season for evidence of deterioration. Replacement should be made of any swing seat that has developed cracks in the plastic seats or has exposed metal in the edges of the swing seat. If there are already exposed metal inserts on the edge of the seat, immediately remove the seats and chains to prevent serious injury. Ropes, cables and chains should be removed and replaced if excessive wear is found. Contact Adventure Playsets for replacement parts.
- 6. For rusted areas on metallic members such as monkey bars, hand supports, brackets, etc., sand and repaint, using a non lead-based paint meeting the requirements of Title 16 CRF Part 1303.
- 7. Inspect wood parts monthly. The grain of the wood sometimes will lift in the dry season causing splinters to appear. Light sanding may be necessary to maintain a safe playing environment. If you are treating your Playcenter with stain regularly, it will help prevent severe checking/splitting and other weather damage.
- 8. We recommend treating the wood components once or twice a year depending on the type of weather you have and when sanding has been required to maintain a good surface. We treat our wood with a waterborne transparent stain.
- 9. Creating and maintaining the Playcenter on a level location is very important. As your children play, your Playcenter will slowly dig its way into the soil, and it is very important that it settles evenly. Make sure the play set is level and true once each year or at the beginning of each play season.

Disposal Instructions:

When the Playcenter use is no longer desired, it should be disassembled and disposed of in such a way that no unreasonable hazards will exist at the time the unit is discarded.

NOMINAL MATERIAL SIZES				
NAME	ED SIZE	TRUI	E SIZE	
Imperial (")	Metric (mm)	Imperial (")	Metric (mm)	
1x6	2.5x15.3	3/4x5x1/2	1.9x14	
5/4x4	3.2x10.2	1x3 1/2	2.5x9	
5/4x6	3.2x15.3	1x5 1/2	2.5x14	
2x2	5x5	1 1/2x1 1/2	3.8x3.8	
2x3	5x7.6	1 1/2x2 1/2	3.8x6.4	
2x4	5x10	1 1/2x3 1/2	3.8x9	
2x6	5x15.3	1 1/2x5 1/2	3.8x14	
4x4	10x10	3 1/2x3 1/2	9x9	
Estimated Sizing Due to Molding of Wood				

APPENDIX A

Information on Playground Surfacing Materials:

The following information is from the *United States Consumer Product Safety Commission's Information Sheet for playground surfacing material* Also see the following website for additional information: www.cpsc.gov/cpscpub/pubs/323.html.

X3. CONSUMER INFORMATION SHEET FOR PLAYGROUND SURFACING MATERIALS¹¹

X3.1 The U.S. Consumer Product Safety Commission (CPSC) estimates that about 100,000 playground equipment-related injuries resulting from falls to the ground surface are treated annually in U.S. hospital emergency rooms. Injuries involving this hazard pattern tend to be among the most serious of all playground injuries, and have the potential to be fatal, particularly when the injury is to the head. The surface under and around playground equipment can be a major factor in determining the injury-causing potential of a fall. It is self evident that a fall onto a shock-absorbing surface is less likely to cause a serious injury than a fall onto a hard surface. Playground equipment should never be placed on hard surfaces such as concrete or asphalt and while grass may appear to be acceptable it may quickly turn to hard packed earth in areas of high traffic. Shredded bark mulch, wood chips, fine sand or find gravel are considered to be acceptable shock absorbing surfaces when installed and maintained at a sufficient depth under and around playground equipment.

X3.2 Table X3.1 lists the maximum height from which a child would not be expected to sustain a life-threatening head injury in a fall onto four different loose-fill surfacing materials if they are installed and maintained at depths of 6, 9, and 12 in. However, it should be recognized that all injuries due to falls cannot be prevented no matter what surfacing material is used.

X3.3 It is recommended that a shock absorbing material should extend a minimum of 6 ft in all directions from the perimeter of stationary equipment such as climbers and slides. However, because children may deliberately jump from a moving swing, the shock absorbing material should extend in the front and rear of a swing a minimum distance of 2 times the height of the pivot point measured from a point directly beneath the pivot on the supporting structure.


X3.4 This information is intended to assist in comparing the relative shock-absorbing properties of various materials. No particular material is recommended over another. However, each material is only effective when properly maintained. Materials should be checked periodically and replenished to maintain correct dept as determined necessary for your equipment. The choice of a material depends on the type and height of the playground equipment, the availability of the material in your area, and its cost.

¹¹This information has been extracted from the CPSC publications "Playground Surfacing — Technical Information Guide" and "Handbook for Public Playground Safety." Copies of these reports can be obtained by sending a postcard to: Office of Public Affairs, U.S. Consumer Product Safety Commission, Washington, D.C., 20207 or call the toll-free hotline: 1-800-638-2772.

The American Society for Testing and Materials takes no position respecting the validity of any parent right asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such parent rights, and the risk of infringement of such rights, are entirely their own responsibility.


The standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either approved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing your should make your views known to the ASTM Committee on Standards. 100 Barr Harbor Drive, West Conshohocken, PA 19428.

The Bellevue Assembly Instructions



Basic Setup Dimensions

Place the set on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.



Parts Identification Wood Components

D LETTER	DESCRIPTION	QUANTITY			
89 1/2"- 6 Rung Monkey Bar Top Ladder (Cranberry) 2A1074-06					
A		————1			
	85 1/2"- 4 Rung Monkey Bar End Ladder (Cranberry) 2A1042-05				
В — — —		———— 1			
	89 1/2"- 3 Rung Fort Ladder (Cranberry) 2A1076-06				
C		2			
D	2x4x89 1/2"- Fort Upright (Cranberry) 4LP1051-06	2			
E — — —	2x4x89 1/2"- Monkey Bar Ground Beam (Cranberry) 4LP1048-06	1			
F — — — —	2x4x44 7/8"- Middle Floor Brace 4L1395-05	1			
G	5/4x4x50 3/8"- Monkey Bar Cross Brace 4L1618-06	2			
H	5/4x4x20 1/4"- Tarp Upright 4L1392-06	2			
1x6x85 1/2"- Fort Ground Beam 4L1613-06					
1 — — — —		2			

Parts Identification Wood Components

ID LETTER	DESCRIPTION	<u>QUANTITY</u>
J — — — —	1x6x39 1/4"- Ground Board 4L1381-05	1
К — — — —	1x6x39 1/4"- Cargo Net Ground Board 4L1382-05	1
L ————	1x4x67" - Monkey Bar Angle Brace 4L1584-06 — —	2
M	1x4x54 7/8" - Angled Floor Support 4L1614-06	4
N	1x4x41 1/4" - Tarp End Cap 4L1389-05 — — — — — [: : :] — — — — —	2
0	1x4x41" - Wall Slat 4L1388-05	4
P — — — —	1x4x39 1/4" - Tarp Support 4L1390-05 — — — — — [] — — — — —	1
Q	1x4x39 1/4" - Fort Rail 4L1391-05	2
R — — — —	1x4x20 1/4" - Cargo Net Rail 4L1393-06 	1
s	1x4x20 1/4" - Rockwall Board 4L1394-05 	6
T — — — —	1x4x20 1/4" - Rockwall Board (no rock) 4L1496-05 	1
U — — — —	54" Floor Panel Assembly 2A1044-06	2

Parts Identification Accessories


1-8' Green Wave Slide - 6P084




3 - Yellow Hand Grips (pair) - 6P002



4 - Fort/Monkey Bar Plate - 6M030



2 - Green Monkey Bar Strip - 6M031




16 - Green L-Bracket - 6M021



1 - Green Roof Tarp - 6F009



2 - Yellow Swing Seats w/chain - 2A1086-06



1 - Adventure Playsets Identification Sticker




2 - Angle Brace Bracket - 6P073




6 - Green Plastic Stakes - 6P085




1 - 3 Rung Cargo Net - 6HCN003



2 - Glider Arms w/chain - 2A1085-06




1 - Glider Seat - 6P083



Hardware Identification

Fort Hardware Bag - 3H1140-06




4 1/4 x 1 1/4" Machine Truss Screw 6HMST11/4

1 1/4" Deck Screws
16 6HS11/4


1/4"

Hardware Identification



Rock Hardware Bag - 6P054

6 Rockwall Rocks (Not Shown)




Measuring hardware

It is very important that you get the right hardware in the correct place when assembling the unit. You can use the ruler below to measure your hardware or you can compare the hardware to the hardware identification page.

NOTES:

- 1) Do not include bolt head when measuring length of bolt.
- 2) Include full length of deck screw when measuring.




Phase 1 Fort Ladder Setup

Items Used in this Phase


(2) Fort Ladder Assemblies 'C'(2) Fort Uprights 'D'

- Step 1: Using a drill with a 3/16" bit, pre-drill a hole approximately $1 \ 1/2$ " deep into each wooden rung on both ladder assemblies. (See Fig 1) This will aid Step 2.
- Step 2: On both Fort Ladders 'C', secure ladder rails to ladder rungs by using a $1\ 1/2$ " tapping screw with fender washer into pre-drilled hole from Step 1 above.



Phase 2 Frame Assembly

- (2) Fort Ladder Assemblies 'C'(2) Fort Uprights 'D'(2) Fort Ground Beams 'I'
- (4) Angled Floor Supports 'M'
- Step 1: Attach (2) Angled Floor Supports 'M' "sandwiched" around the cranberry posts on Fort ladder with (4) 3 1/4" Hex Bolts, fender washers and lock nuts. (see Fig 2)
- Step 2: Attach (1) Angled Floor Support 'M' to inside of Fort Ladder on the side opposite the attached boards from 'Step 1'. These boards will attach with (4) 2 1/2" hex bolts, fender washers and lock nuts.
- Step 3: Attach (1) Ground Beam 'l' to outside botttom of Fort Ladders with (2) 2 1/2" hex bolts, fender washers and lock nuts.
- Step 4: Attach (1) Floor Support 'M' and (1) Ground Beam 'l' to Fort Uprights with 2 1/2" hex bolts, fender washers and lock nuts as shown. (you must have the correct end of Upright 'D' facing up or improper assembly will result. See Phase 1)




Phase 3 Frame Assembly Cont.

Items Used in this Phase
(1) Ground Board 'J'
(1) Cargo Net Ground Board 'K'


Step 1: Attach (1) Ground Board 'J' & (1) Cargo Net Ground Board 'K' to the bottom of the fort frame with (6) 2 1/4" deck screws each. The boards should be flush with the ground before attaching.

NOTE: Make sure the boards are on the correct side before attaching. Note the hole orientation of Cargo Net Ground Board 'K'.



Phase 4 Floor Attachment

- (1) Middle Floor Brace 'F' (2) Floor Panels 'U' (12) Green L-Brackets
- Note: It is crucial that the playset is level and square before and during floor attachment. You may need to make adjustments on the set while installing floor to insure the set remains square.
- Step 1: Place Floor Panels 'U' on top of the Angled Floor Supports 'M' and attach with L-Brackets & 3/4" tapping screws as shown in Fig 3. Make sure the floor panel is centered on the fort and has equal overhang on each side.
- Step 2: From underneath the playset, center Middle Floor Brace 'F' in the gap between the (2) middle floor supports 'M' and flush with the top of the Floor Panels 'U' and attach with (8) 2 1/4" deck screws as shown in Fig 4. (make sure 'F' is flush with the top of the Floor Panels 'U')






Fig. 3





Fig. 4



Phase 5 Rockwall Attachment

- Step 1: Attach Cargo Net Rail 'R' to Upright 'D' and the middle ladder rail with (4) 2 1/4" deck screws. The board will attach flush with the bottom of the Floor Panel 'U'. See Fig 5. (Make sure 'R' is placed on same side of fort as Cargo Net Ground Board 'K')
- Step 2: Gather the (6) Rockwall boards 'S' and hammer 3/8" t-nuts into the large hole on each board. (see Fig. 6)
- Step 3: Install the first Rockwall Board 'S' by placing the board flush with the bottom of the floor where shown and attaching to uprights with (4) 2 1/4" deck screws. (the t-nut must go to the inside of the fort.)
- Step 4: Place remaining (5) Rockwall boards 'S' below the previously attached board, spaced 2 5/8" apart.

 Boards must be placed so the rock holes alternate sides and NOT placed in a straight line. (Note: Place boards from top to bottom.) (See Fig. 8)
- <u>Step 5:</u> Attach Rockwall Board 'T' to fort equally spaced below last Rockwall Board 'S'.
- Step 6: Attach Rockwall Rocks to each Rockwall Board 'S' with 3/8" flat head bolt through rock and board and into previously placed t-nut, and with 1 1/4" deck screw as shown. (see Fig 7)

- (1) Cargo Net Rail 'R'
- (1) Rockwall Board (no rock) 'T'
 - (6) Rockwall Boards 'S' (6) Rockwall Rocks




Fig. 5





Fig. 6






Fig. 7





Fig. 8

Phase 6 Cargo Net/ Fort Rail Attachment

- (2) Fort Rails 'Q'
- (1) Cargo Net
- (6) Hand Grips
- Step 1: Attach Cargo Net to Cargo Net Board 'R' with 1 1/2" hex botls with fender washers through the cargo net loops and Cargo Net Board and into a fender washer and lock nut on the backside. (see Fig 9)
- <u>Step 2:</u> Attach Cargo Net to Cargo Net Board 'K' by feeding the rope through the front of the 2 large holes and tying a knot tight on the backside of the board 'K'. (see Fig 9)
- Step 3: Attach Fort Rails 'Q' to the tops of the fort as shown with 2 1/4" deck screws. The edge of Q must be flush with the ends of the Uprights. (see Fig 10)
- Step 4: Attach (1) hand grip to the side of each Upright and Ladder Rail with 1 1/2" tapping screws. There will be (3) hand grips per side of fort and they should be placed 20" down from the bottom edge of Fort Rails 'Q'. (see Fig 10)






Fig. 9






Fig. 10

Phase 7 Roof Assembly

- (2) Monkey Bar Cross Braces 'G'
 - (2) Tarp Uprights 'H'
 - (2) Tarp End Caps 'N' (1) Tarp Support 'P'
- Step 1: Attach Tarp Uprights 'H' to Monkey Bar Cross Braces 'G' with 2 1/2" hex bolts, fender washers and lock nuts.
- <u>Step 2:</u> Attach Tarp End Caps 'N' to the ends of Monkey Bar Cross Braces 'G' with 2 1/4" deck screws as shown.
- Step 3: Attach Tarp Support 'P' to top of Tarp Uprights 'H' with 2 1/4" deck screws as shown.





Phase 8 Roof Attachment


Items Used in this Phase

Phase 7 Roof Assembly (2) Green Fort Plates

Step 1: The Roof Assembly Attaches differently on the back of the fort than it does on the front.

- a:) Attach Roof Assembly to the front of the fort with (2) $2 \frac{3}{4}$ " hex bolts, fender washers and lock nuts as shown.
- b:) Attach Assembly to the back of unit by placing a 3" hex bolt with a fender washer through Fort Upright, then through top hole on Fort Plate and then through Cross Brace 'G' and into a fender washer and lock nut. (see Fig. 11, 12 & 13) Do Not tighten this screw down tight, it will be temporarily removed in a later phase.

Step 2: Attach the fort plate to the Uprights and Monkey Bar Cross Brace with 1" tapping screws through open holes. (the long edge of the plate will run parallel with the edge of the uprights) (see Fig. 11 & 13)



Phase 9 Tarp & Wall Slat Attachment

| Items Used in this Phase | (4) Wall Slats 'O' | Adventure Playsets ID Sticker (1) Green Roof Tarp

- Step 1: Drape Tarp over Tarp Support 'P' and Tarp End Caps 'N'. Attach one side of tarp to inside of one Tarp End Cap 'N' with (3) 3/4" tapping screws. Pull other side of Tarp tight and attach to inside of other Tarp End Cap with 3/4" tapping screws. (see Fig 14 & 15)
- Step 2: Attach one end of each Wall Slats 'O' to the inside of the Monkey Bar Cross Braces 'G' with

 (2) 1 1/4" deck screws and attach the other end to the outside of Angled Floor Supports 'M'

 with (2) 1 1/4" deck screws each. (the Wall Slat should be spaced 3 1/4" away from upright)

 See Fig 16.
- <u>Step 3:</u> Peel backing off of the Advenute Playsets ID Sticker and place sticker on front of tarp where shown.





Fig. 15

Phase 10 Monkey Bar Setup

- (1) Monkey Bar Top Ladder 'A'
- (1) Monkey Bar End Ladder 'B'
- (2) Green Monkey Bar Strips
- Step 1: Using a drill with a 3/16" bit, pre-drill a hole approximately 1 1/2" deep into each wooden rung on each Ladder Assembly. This will aid Step 2 & 3. (see Fig 17)
- Step 2: Secure Metal Strip to each side of the Monkey Bar Top Ladder 'A' WHERE SHOWN with $1 \frac{1}{2}$ " tapping screws & fender washers through pre-drilled holes and into each ladder rung.
- Step 3: On both Ladders, secure ladder rails to rungs by using a 1.1/2" tapping screw & fender washer through pre-drilled holes as shown. (secure both sides with tapping screws)




Phase 11 Swing Hanger Attachment

Items Used in this Phase

- (1) Monkey Bar Top Ladder 'A'
- (8) Swing Hanger Lag Screws

<u>Step 1:</u> Screw lag screw swing hangers into pilot holes on Monkey Bar Top Ladder in pattern shown below. (Note, for future reference, where each swing activity will attach)






Fig. 18



Note: Swing hangers must be installed according to hardware illustration above!


Phase 12 Monkey Bar Assembly

Items Used in this Phase

- (1) Monkey Bar Top Ladder 'A'
- (1) Monkey Bar End Ladder 'B'
 - (2) Monkey Bar Plates
 - (4) Green L-Brackets


Step 1: Attach Monkey Bar Top Ladder 'A' to Monkey Bar End Ladder 'B' with metal Monkey Bar Braces between the two as shown with hardware shown in Fig 19. (Make sure Swing Hangers point down.)

Step 2: Attach (2) L-brackets to the end of each Top Ladder rail with hardware shown. (see Fig 20)




Phase 13 Monkey Bar Assembly

- (1) Monkey Bar Ground Beam 'E'
- (2) Monkey Bar Angle Braces 'L' (2) Angle Brace Brackets
- Step 1: Attach Angle Brackets to Angle Braces 'L' with 1 1/2" Hex Bolts as shown in Fig 21.
- Step 2: Attach Angle Braces 'L' to Monkey Bar Ground Beam 'E' with 2 1/2" hex bolts, fender washers and lock nuts as shown.
- Step 3: Attach Angle Braces 'L' to End Ladder 'B' with 2" hex bolts & hardware shown in Fig 22.
- Step 4: Attach Monkey Bar Ground Beam 'E' to End Ladder 'B' with 2 1/2" tapping screws with fender washers.



Phase 14 Monkey Bar Attachment

- Step 1: Remove the (2) 3" hex bolts on the back of the unit that attach the tarp roof assembly. (see Phase 8)
- <u>Step 2:</u> Attach Monkey Bar Assembly to Monkey Bar Cross Brace 'G' by placing the "Removed" 3" hex bolt back through the hole it was removed from and through the outside L-brackets on the end of the Top Ladder.
- Step 3: Attach the (2) inside L-brackets on the Top Laddder to the Monkey Bar Cross Brace 'G' with 1" tapping screws and washers as shown. (see Fig. 23)



Phase 15 Glider Assembly

Items Used in this Phase

(2) Glider Arms w/Chain (1) Glider Seat


Step 1: Insert glider seat into glider arms & attach with (2) 6" hex bolts, (4) fender washers & (2) lock nuts as shown.

<u>Step 2:</u> After assembly is complete, attach glider assembly to swing hangers located on monkey bar top ladder. (see Phase 11)

Step 3: Attach Swing Assemblies to swing hangers located on monkey bar top ladder. (See Phase 11)

Note: Make sure swing hangers are closed tightly with a wrench, so that they cannot be opened by hand.

Note: You may need to adjust the height of the glider and swings with the chain so that the glider is at least 8" off the ground.



Phase 16 Slide Attachment


Items Used in this Phase


(1) Wave Slide

Step 1: Center the wave slide in the opening opposite the monkey bar.

Step 2: Using a drill with a 5/16" bit, drill a hole through the indentions on the slide and through the fort floor board. (outside floor board)


Step 3: Insert a 1/4" T-nut under the floor into drilled hole, and attach slide with 1/4"x1 1/4" Machine truss screw and washers as shown in Fig. 24 below.





Phase 17 Anchoring Instructions

Step 1: Drive Stakes into ground against boards where shown below and attach with (1) 1 3/4" deck screw each as shown in Fig. 25.



Frequently Asked Questions

Q: What size of play area do you recommend around the playset so my child may play safe??

A: We recommend at least a six-foot play perimeter around the playset.

Q: My swing set seems to sway or rock too much. What is wrong?

A: Rocking is caused my uneven ground or obstructions such as rocks, roots, etc. under the ground rails. These obstructions should be removed and the ground underneath leveled to prevent rocking. If the fort itself is moving, it is usually caused because the fort is not staked down. Staking is required and will stop most of the movement.

Q: The end ladder is not straight up and down. What is wrong?

A: Nothing is wrong. The end ladder does not form a 90° angle. It has an angle to it.

Q: The top ladder does not have holes for the swing hanger lags. Why not?

A: The top ladder is probably installed upside-down.

Q: My wood appears to be cracking. Is that a problem?

A: No, expansion and contraction of wood due to weather changes will cause slight cracking (technically called checking) and distortion. These are natural characteristics of wood and do not affect the structural integrity of the playset.

Q: My 2x4 boards do not measure 2"x4". Why not?

A: It has been common practice in the U.S. to use the rough-cut dimension from a sawmill to describe the width and height of a particular piece of lumber. Many retailers, designers, contractors and manufactures utilize this description with a common and accepted knowledge that the actual size will vary from this description. Our sets are designed using the actual dimension. This ensures the sets will be assembled properly and be safe for the recommended use.

Q: How often should I re-stain my playset and what should I use?

A: The playset should be checked at least once a year depending on the weather. Lightly sand any rough areas and re-stain the set with a waterborne transparent stain.

CUSTOMER NOTES

		•
		_
		_
		_
		_
	·	

CUSTOMER NOTES

Limited Warranty

Adventure Playsets Inc. insures to the original owner of our product, that the components of our set are free from defect in materials and will be warranted for one year from the date of purchase. In addition, all wooden components will be warranted against rot or insect damage for 12 Years to the original owner. All non-wood components will carry a one-year warranty only.

All defective parts that are discovered and reported in the first thirty days after purchase will be replaced at no charge to the registered customer. After thirty days of purchase shipping and handling charges for replacement warranty parts will be passed on to the consumer.

All returned goods will be accessed by our customer service department. We will not accept any goods without an authorization code. Our customer service department will give out all codes. Failure to supply authorization code with shipment will void all said warranty. Our customer service department can be reached at 1-800-856-4445.

This Limited Warranty does not cover the following:

- □ The cost of labor required to re-install or disassemble the defective component.
- □ The cost of <u>air</u> freight
- □ The cost of freight after the initial 30 days from purchase.
- Cosmetic defects that do not affect the structural integrity of the play center.
- Any abnormal conditions such as vandalism, improper installation, misuse or abuse, or improper maintenance.
- Damage done by nature such as wind, lightning, severe weather, etc...
- Natural defects of wood such as warping checking or any other physical properties of wood that do not present a hazard.

Adventure Playsets products have been carefully designed to insure your child's safety. Any modifications to your playsystem could result in serious injury as well as void all warranties.

Our playsets are designed for Residential use only, for children between the ages of 3 and 10, for a single-family dwelling. Commercial use such as nurseries, parks or schools, voids all warranties and liabilities.

Warranty claim procedure

If you are confident that your playsystem has been installed and maintained properly, and you have a warranty claim, proceed with the following steps:

- 1. We will need copy of your proof of purchase (Vendor sales receipt only.)
- 2. We require a brief written description of the warranty issue.
- 3. Photos of warranted parts and of the entire play system.

If **any** of the above steps are not completed, there may be delays in the completion of your claim, or possibly warranty cancellation.

Mail information to:

Adventure Playsets 14201 I-27 Amarillo, Texas 79119

or email at custservice@adventureplaysets.com

Our customer service department will review the claim and make contact with the customer by mail or by phone. The customer will only pay for shipping and handling to and from factory if warranty is approved.

1-800-856-4445

Service department hours Monday thru Friday 9am to 5pm Saturday 9am to 2pm Central standard time

Customer Registration Card

Name:			
Address:			
City:		State:	Zip:
Home Phone:			
Date of Purchase:		Date Stamp	oed on Box:
Vendor Name:			
City:		State:	Zip:
Unit Model: <u>1-AP012-06</u>	Unit Name: The Be	ellevue - 2006	
Please check the boxes belo	ow:		
How old are you? ☐18-30	□ 31-43	<u>44-56</u>	Older than 56
How would you rate the Above Average		luct? Fair	Poor
How would you rate the Above Average		of our product?	Poor
How would you rate ou Above Average		☐ Fair	Poor
Would you recommend ☐Yes	our product to frien	nds & family?	
How old are your child: ☐ 3-4	ren?	□ 7-8	9-10
Where did you hear abo ☐ Friend	out us?	Advertise	ement Internet
Comments:			



Customer Registration Card

Do not forget to send in your registration card to the factory. This card will validate your time of purchase for warranty items.

Fold here

Place stamp here

Adventure Playsets 14201 I-27 Amarillo Texas, 79119

THIS IS YOUR UK WARRANTY CARD - PLEASE RETAIN THIS PART

YOU WILL NEED TO QUOTE THE DETAILS BELOW TO OBTAIN PARTS UNDER WARRANTY

The	Bel	levu	E
1-A	P01	2-06	6

Purchased from:	[Date:
Plum PRODUCTS		uiries: 08700 170 580 (UK)
*		
TO VAL	IDATE UK WARRANTY	- PLEASE RETURN THIS PART
PLEASE RETURN THE		CUSTOMER DETAILS:
COPT OF TOUR SAL	LES RECEIPT TO.	Name:
PLUM PRODUCTS DISTRIBUTION CENTRE DEPT REG INGHAM		Address
LINCS		
LN1 2YQ		Postcode:
		1 031000C
Purchased from:		Purchase Date:

The Bellevue 1-AP012-06